
Staple Ease™ Benefits: Labor Saving, Reduce Fatigue, Install Staples Right™







Staple Pro[™] 1011 Staple Driver Instruction Sheet

Thank you for purchasing the Staple Ease Staple Pro Driver. The Staple Pro™ driver is a one-by-one load system that uses a slide hammer action to install staples from soft soil conditions to hard, compacted ground conditions – even frozen ground.

The Staple Pro 1011 Drivers use standard U-shape 11-gauge and thicker 10-gauge wire staples from 4" (10 cm) to 8" (20cm) in length.

How to use:

- Bring the driver up to waist level, keeping the bottom of the driver facing downward.
- 2) LOAD: Insert a staple into the driver through the bottom chamber.
- 3) POSITION: Place driver on the ground or over drip irrigation lines or wire.
- 4) PUMP: Use the handle like you would a slide hammer or bicycle pump and drive the staple into the ground with two to six pumps. (Depends on how hard the ground is)
- 5) If the staple is not installed completely, place the driver over the staple and hammer it with the slide hammer to continue the installation.
- · In softer ground, you may be able to install the staple in one or two slide hammer pumps. In compact soils, it may take three to six pumps to install. Please adjust use of the tool on the ever-changing soil conditions.

Troubleshooting

- If a staple gets jammed, bring the driver to waist level and push the handle as far as it will go. The staple should be pushed far enough through to be removed.
 Be careful to watch fingers. Use pliers to avoid any injury.
- · Apply a small amount of WD-40 or equivalent near the insertion point of the rod to the bottom of the driver if there are any issues with the rod sticking.

Cleaning

- Placing muddy drivers into a bucket of water will help clean the bottom of the driver where dirt, mud and debris can accumulate.
- Using the driver once dirt has dried should clear out any debris. Staple Ease is designed to be rust-free.

Storage

 Store the Staple Pro driver in a dry place like you would any other tools or mechanical equipment such as lawn mowers or saws.

Warnings

- · Keep the bottom of the driver away from feet or hands when in use.
- · Do not point and shoot staples at anyone.
- · Do not staple through anyone's body parts as serious injury or death can occur.
- · Wear safety glasses and gloves when installing staples.



